Hidden Pen-Type Camera & Video Recorder



640 x 480 AVI • 25fps Recording • High Capacity Rechargeable Li-on Battery

Description

Time Setup

- Insert the CD that came in the box on the
- Open CD driver then go to Time Set folder and run exe WriteTime windows will appear on the screen (sometimes takes time to load)
- Insert the USB Pen DVR to the PC
- On the WriteTime windows enter the date/time information as shows below and then press “Update” Year-Month-Date (space) Hour:Minute:Second

Video Recording

- Switch the mode to **Video** as shown the diagram at the
- Press and hold the button on the top (about 5 sec).

The light will blink few times and stay in orange light (standby mode).

- Press the button again (short press) to start The light will change to blue.
- Press the button again (short press) to stop The light will change back to orange (standby mode).
- Press and hold the button (about 5 sec) to turn

Photo

- Switch the mode to **Photo** as shown the diagram at the
- Press and hold the button on the top (about 5 sec).
- The light will blink few times at first and then orange light will blink slowly (standby mode).
- Press the button again (short press) to take a
- The light will stay in blue about 5 sec, and then change back to orange blink (standby mode).
- Press and hold the button (about 5 sec) to turn